
100



FIGURE!

DESCATOR TEREST

FIGNE 2

FIRURE 40.

SEND A COMMAND TO THE HOME AUTOMATION CONTROLLER FROM THE HOME AUTOMATION APPLICATION TO CONTROL AN OPERATION OF A LOAD COUPLED WITH THE HOME AUTOMATION CONTROLLER

410

USE THE HOME AUTOMATION
CONTROLLER TO CONTROL THE
OPERATION OF THE LOAD IN
RESPONSE TO THE COMMAND FROM
THE APPLICATION

420

FIRURE 5

SEND A SIGNAL FROM THE HOME SECURITY CONTROLLER TO THE HOME SECURITY APPLICATION TO INDICATE THAT A SENSOR HAS BEEN TRIGGERED

510

USE THE HOME SECURITY APPLICATION TO ACTIVATE AN ALARM IN RESPONSE TO THE SIGNAL

520




Figure 6

